MARTHA STEWART LIVING™

Christmas Tree
Sku # 474305

SAVE THESE INSTRUCTIONS

IMPORTANT: Do not remove bulbs with the green ring base. These bulbs are safety-fused bulbs and removing them will permanently damage the light string and void the limited warranty of this product.



Pre-Assembly

Package Contents

Part	Description	Quantity
A	Top part of Tree	1
B	Middle part of Tree	1
C	Bottom part of Tree	1
D	Pot	1

Assembly

Assembling the tree

Step 1. Choose a location near a wall outlet or have an extension cord plugged in and ready to use.

Step 2. Lay the pot (D) on the floor and insert the pole of the Bottom part of Tree (C) into the Pot.

Step 3. Insert the pole of the Middle part of Tree (B) into the top of the Bottom part of Tree (C).

Step 4. Insert the pole of the Top part of Tree (A) into the Middle part of Tree (B).

Step 5. Shape the branches to your preference by working from the bottom of the top. When adjusting branches ensure that all wires are free of branch hinges.

Step 6. When finished shaping the branches, slightly upsweep all branch tips for a uniformed look.

Roundtripping Ltd.
Hong Kong, China
All Rights Reserved
Printed in China



Roundtripping Ltd.
Hong Kong, China
All Rights Reserved
Printed in China

Operation

Turning on the tree

NOTE: If some bulbs do not light or flicker, search for any loose plugs and/or broken, loose, or missing bulbs. Replace bulbs promptly with the replacement bulbs provided in order to maintain the performance and life expectancy of your tree.

Step 1. Connect the light strings of the tree sections together and plug the power cord into a wall outlet or approved power cord.

Maintenance

Spare parts

This tree package includes replacement bulbs and fuses for your tree.

Care and Cleaning

Step 1. Remove all ornaments and decorations.

Step 2. Unplug the cord from the wall and then unplug each section of the tree.

Step 3. Gently lift the tree Top straight up to remove from the MIddle section and fold all branches towards the pole.

Step 4. Repeat this step for the Middle and Bottom tree sections.

Step 5. Carefully place all tree sections into a storage box and secure the cover.

Step 6. Store your tree in a cool, dry place away from sunlight.

Troubleshooting

Problem	Solution
The tree does not Light	Ensure that all tree sections are plugged into each other and that the tree is plugged into a power source. If your tree came with a foot pedal, step on the On/Off button.
	Check for blown fuses on the light string and power cord plugs. Replace as needed with the replacement fuses provided.
	Check for loose, broken, or missing bulbs and replace as needed with the replacement bulbs provided

FOR INDOOR AND OUTDOOR USE
MODEL NO. TOL-50LB TOL-100L/2WB